

FAQ

Installation Instruction :

1. Plug two speaker cables into either speaker output jack left or right on rear of the amplifier (Stripy House)
2. Plug the power cord (adaptor) into DC outlet (middle jack) on rear of the amplifier
3. Signal input cable of amplifier plug to audio out on your pc or audio source.
4. Finally, plug the power adaptor into the wall power socket.
→ A light blue flashy will appear when fully plugged in.

Function Activate :

Press and Hold for 3 seconds → On / OFF (Pink is On, Off is lightless)

Function color indicator :

Pinky White for Volume → **Diamond Blue for Bass** → **Garden Green for Treble**

(1st Press) → (2nd press) → (3rd Press)

Anytime press swift twice : **Red for Mute** (for mute deactivate, simply touch or turn around the volume knob)
turns the nifty control knob to Right **for louder**; **Left for lower**, four flashy lights to be indicated.
one flashy light to be indicated when volume level is in middle.

Volume level :

Any pre-used default will be stored for next power on, except the electric plug is drawn out.

For any pre-used default clearness, just draw out the electric plug for few seconds.

Speaker product weak or no sound :

1. Re-check all the connections are fully plugged in. (two Speaker plugs, Amplifier plug, Power adaptor)
2. Check your music sources or audio devices' volume level
3. Turn Stripy's volume knob to the right direction for louder

Distortion :

If you feel any distortion sound happened, we suggest you to reduce a bit volume to get the best sound enjoyment!